

How to measure your room and stairs



Step 1



Measuring Your Rooms:

1. Use a tape measure, Apple 'measure' app or preferably a laser measure for the works.
2. Measure the following dimensions:
 - o Height (vertical length from floor to ceiling)
 - o Width (horizontal length from corner to corner, usually the shortest dimension)
 - o Length (longest dimension of the room)
3. Enter the following dimensions of the YDIY calculator for the total room area (m^2)

Step 1

Measuring Your Stairs:

1. Select the option "Hall/Stairs/Landing" to include measurements for the hall, stairs, and landing.
2. Two room options will be displayed:
 - o Enter your Landing dimensions.
 - o Enter your Hallway dimensions.
3. The scaffolding required for the stairs will be automatically calculated.



How to check that the walls are in suitable condition for painting



Step 2



Undertake a visual check to ensure walls are paintable and check for:

- o Flaking
- o Dampness
- o Mould
- o Large/Deep holes
- o Blistering

Step 2

If found please answer **NO** to the Prior Works questionnaire questions “Are walls in suitable condition to be painted on (see guide)?” and provide photographic evidence via uploading images onto the portal. This will trigger a written disclaimer to the customer that it is then their decision on whether to continue the works.

